


INSTRUCTIVO DE INSTALACIÓN

LEA EL INSTRUCTIVO

CANDIL DE 6 LUCES



¿Preguntas, problemas o piezas faltantes? Antes de regresar a la tienda, llame al Servicio al Cliente de Decor Living de lunes a viernes entre 9:00 a.m. y 5:00 p.m., EST **800-936-3213**

INSTRUCTIVO

Favor de leer este instructivo completamente antes de instalar y operar el luminario. Consulte el instructivo para futuras referencias. **Decor Living** Brooklíte México S de RL de CV Ave. José Vasconcelos 638 Piso 3 Valle Del Campestre San Pedro Garza García 66265 NL, México RFC: BME110829587 Tel: 800-354-8464 customersupport@enchlites.com


DESCRIPCIÓN: LUMINARIO DECORATIVO
 MARCA: DECOR LIVING
 MODELO: CH2006HM
 CARACTERÍSTICAS ELÉCTRICAS:
 120 V~ 60 Hz 6 X 40 W 3 A
 UTILIZA SEIS LÁMPARAS INCANDESCENTES DE 40 W
 CONSUMO DE ENERGÍA EN OPERACIÓN: 235.8 Wh
 Hecho en China / Cantidad Una Pieza



Herramientas Necesarias



Herrajes Incluidos



Contenido del Paquete

- A - Soporte de Montaje
- B - Base
- C - Pieza Central
- D - Varilla de 30cm (x2)
- E - Varilla de 55cm (x2)
- F - Lámpara
- G - Pantallas de Vidrio Transparente (x6)
- H - Pantallas de Vidrio Esmerilado (x6)
- I - Tuerca de la Lámpara
- J - 40W Bombilla E26 (x6) (No Incluidas)

Instalación

ADVERTENCIA: Apaga la electricidad en la caja de fusibles (o cortacircuitos) antes de comenzar la instalación desconectando el cortacircuitos o sacando el fusible.

ADVERTENCIA: Conductores de corriente, mínimo 90° C (194° F)

ADVERTENCIA: Si el cordón toma corriente es dañado, debe ser sustituido por personal autorizado por electricista capacitado.

PRECAUCIÓN: Consulta a un electricista calificado para garantizar una conexión correcta del conductor del circuito derivado.

Instalación de el soporte de montaje

Coloque el soporte de montaje (A) sobre la caja de salida para determinar dónde perforar los agujeros. Retire el soporte de montaje (A) y taladre agujeros de .32 cm.

Fije el soporte de montaje (A) en los orificios perforados y fíjelo atornillando los tornillos de la máquina (CC) en los orificios. Asegúrese de que todos los cables del circuito sobresalgan de la caja de salida.

Conexiones eléctricas

NOTA: Si el circuito de alimentación no tiene un cable de tierra, conecte el cable de tierra del accesorio al tornillo verde (no se muestra). Nunca conecte el cable de tierra a los cables de alimentación negro o blanco.

Pele 1.9cm de aislamiento de los extremos del cable de la lámpara y los cables del circuito de suministro.

Conecte el cable de tierra del circuito de suministro (cable de cobre desnudo) al cable de tierra de la lámpara y asegure la conexión con una tuerca para cable (BB).

Tuerza los extremos del cable pelado del dispositivo y los cables del circuito de suministro: negro (L) a negro y blanco (N) a blanco.

Gire las tuercas para cable (BB), asegurándose de que los conductores ya no estén expuestos.

Cuidadosamente meta los cables conectados y las tuercas para cable (BB) en la caja de salida.

Instalacion de la base y de las varillas

Alinee los orificios de la base (B) con los orificios en el soporte de montaje (A).

Asegurar la base (B) en su lugar enroscando los tornillos decorativos (DD) a los tornillos de montaje (AA).

Conecte las varillas (D,E) juntas, luego conecte cada lado de las varillas (D,E) al pieza central (C) y la base (B).



Conecte cada lámpara (F) a la pieza central (C)

Instalación de las pantallas y la bombillas


Fije las pantallas de vidrio transparente (G) a la lámpara (F) y luego fije las pantallas de vidrio esmerilado (H) dentro de las pantallas de vidrio transparente (G). Asegure en su lugar con la tuerca de la lámpara (I).

Luego instale las bombillas (J). Sólo utilice bombillas del tipo especificado y del voltaje indicado o menor.

Esta lámpara utiliza seis 40 Watt (máx.) bombillas E26 (no incluido).



INSTALLATION INSTRUCTIONS
READ THE INSTRUCTIONS
6 LIGHT CHANDELIER



Questions, problems, missing parts? Before returning to the store, call Decor Living Customer Service 9:00 a.m. - 5:00 p.m., EST, Monday-Friday 800-936-3213

Imported by:
 Brooklite México S de RL de CV
 Ave. José Vasconcelos 638 Piso 3 Valle Del Campestre
 San Pedro Garza García 66265 NL, México
 RFC: BME110829587
 Tel: 800-354-8464
 customersupport@enchlites.com

www.decorliving.mx
 decorlivingmx
 decorivingmexico



Warranty

LIMITED WARRANTY
 Manufacturer warrants that the Products sold hereunder will be free from defects in material and workmanship for a period of two (2) years from the date of purchase. If the Products do not conform to this Limited Warranty during the warranty period (as herein above specified), Buyer shall notify Manufacturer in writing of the claimed defects and demonstrate to Manufacturer's satisfaction that said defects are covered by this Limited Warranty. If the defects and proof of purchase are properly reported to Manufacturer within the warranty period, and the defects are of such type and nature as to be covered by this warranty, Manufacturer shall, at its own expense, furnish replacement Products or, at Manufacturer's option, replacement parts for the defective Products. Shipping and installation of the replacement Products or replacement parts shall be at Buyer's expense.

EXCLUSIVE OBLIGATION
 THIS WARRANTY IS EXCLUSIVE. The sole and exclusive obligation of Manufacturer shall be to repair or replace the defective Products in the manner and for the period provided above. Manufacturer shall not have any other obligation with respect to the Products or any part thereof, whether based on contract, tort, strict liability or otherwise. Under no circumstances, whether based on this Limited Warranty or otherwise, shall Manufacturer be liable for incidental, special, or consequential damages.

OTHER STATEMENTS
 Manufacturer's employees or representatives' ORAL OR OTHER WRITTEN STATEMENTS DO NOT CONSTITUTE WARRANTIES, shall not be relied upon by Buyer, and are not a part of the contract for sale or this limited warranty.

ENTIRE OBLIGATION
 This Limited Warranty states the entire obligation of Manufacturer with respect to the Products. If any part of this Limited Warranty is determined to be void or illegal, the remainder shall remain in full force and effect.

Required Tools



Included Hardware



Package Contents

- A - Mounting Bracket
- B - Canopy
- C - Center Piece
- D - 11.8-in Pole (x2)
- E - 21.6-in Pole (x1)
- F - Fixture
- G - Clear Glass Shades (x6)
- H - Frosted Glass Shades (x6)
- I - Socket Nut
- J - 40W E26 Bulb (x6) (Not Included)

Installation

WARNING: Turn off the electricity at the main fuse box (or circuit breaker box) before beginning installation by switching the circuit breaker off or removing the fuse.

WARNING: Min 90°C (194° F) supply conductors.

WARNING: If cord is damaged, socket must be replaced by a qualified electrician or trained professional.

CAUTION: Consult a qualified electrician to ensure correct branch circuit conductor.

Installing the mounting bracket

Place the mounting bracket (A) over the outlet box to determine where to drill holes. Remove the mounting bracket (A) and drill 1/8-in holes.

Fasten the mounting bracket (A) onto the drilled holes and secure by screwing the machine screws (CC) into the holes. Ensure all supply circuit wires protrude out of the outlet box.

Making the electrical connections

NOTE: If the supply circuit does not have a ground wire, attach the fixture ground wire to the green screw (not shown). Never connect the ground wire to the black or the white power supply wires.

Strip 3/4-in of insulation from the wire ends of the fixture and from the supply circuit wires.

Attach the supply circuit ground wire and fixture ground wire (bare copper wire) to the mounting bracket (A) using the green screw (EE). Secure the connection with a wire nut (BB).

Twist the stripped wire ends of the fixture and the supply circuit wires together: black (L) to black, and white (N) to white. Twist on the wire nuts (BB), ensuring that the conductors are no longer exposed.

Carefully tuck the connected wires and the wire nuts (BB) into the outlet box.

Installing the canopy and pole sections

Align the canopy holes (B) with the holes on the mounting bracket (A). Secure the canopy (B) into place by screwing the two decorative knobs (DD) to the mounting screws (AA).

Attach poles (D,E) together and attach each end to the center piece (C) and canopy (B). Tighten the poles (D,E) to the center piece (F).

Attach each fixture (F) to the center piece (C).

Installing the Shades and the bulbs

Attach the clear glass shades (G) to the fixture (F) then add the frosted glass shades (H) inside the clear glass shades (G). Secure in place with the socket nut (I).

Install the bulbs (J). Only use a bulb of the specified type and maximum rated wattage or less.

This fixture uses six 40 Watt (max.) E26 bulbs (not included).

